

# Agile™



**Product Name:** Agile™ 12 Ammo Cabinet Drawer

**Product Number:** AG-AC12-DRAWER

## **What's Included:**

Agile™ 12 Ammo Cabinet  
Override Keys (2)

Mounting Hardware Kit

## **Product Specifications:**

- W x D x H (External) 20.25" x 15.25" x 12"
- W x D x H (Internal) 16.75" x 14.25" x 9.5"
- Depth of 30.5" with the drawer fully extended, including the depth of the handle and key
- Weight: 50.8 pounds
- Made from 14 Gauge Steel

**Do not throw away the packaging until you've located the override keys.**

The Agile™ Ammo Cabinet arrives locked, with the override keys attached to the drawer's handle.

Fully insert the key and turn counter-clockwise 90 degrees to unlock. Turn the key clockwise 90 degrees to lock. The key can be removed from the lock in the unlocked position.

## **Drawer Removal:**

1. Unlock the cabinet and pull out the drawer fully.
2. Locate the rails on the left and right sides of the drawer.
3. Push the plastic tab on the left side of the drawer up and the tab on the right side of the drawer down, then pull the drawer out of the cabinet.
4. To reinstall the drawer line up the rails on the drawer and cabinet, and then push the drawer into the cabinet.



**Contact Us  
Here**

**Do you have questions or need help?**

**Email:** [Support@SecureItTactical.com](mailto:Support@SecureItTactical.com)

**Phone:** 1-800-651-8835

**Hours of Operation:** 8:00 AM - 4:30 PM Eastern,  
Monday through Friday



**See Our Warranty and  
Return Policies Here**

The Agile™ 12 Ammo Cabinet can be used as a stand alone cabinet or it can be mounted under or on top of another Agile™ cabinet.

## Mounting your Ammo Cabinet to an Agile™ Cabinet

Hardware Parts List:

H-1. Screws (4 ct.)

H-2. Fender Washers (8 ct.)

H-3. Nylon Lock Nuts (4 ct.)



H-1.



H-2.



H-3.

### Tools Needed:

10mm Wrench

Phillips-Head Screwdriver

**WARNING: Serious injuries can occur from safe tip-over.**

**Always mount the lower cabinet to the floor or wall before installing and mounting the upper cabinet.**

**Step 1** – Anchor the lower cabinet to the floor or wall before mounting the upper cabinet on top.

**Step 2** – Safely lift and place the upper cabinet on top of the lower cabinet.

**Step 3** – Insert a screw (H-1) through a fender washer (H-2), then push the screw through the hole on the bottom of the upper cabinet into the hole on the top of the lower cabinet.

Repeat this step for the three remaining mounting holes.

**Step 4** – Inside the lower cabinet, slide a fender washer (H-2) over the screw (H-1), then hand tighten a nylon lock nut (H-3) onto the screw.

Repeat this step for the three remaining screws.

**Step 5** – Use a screwdriver and wrench to tighten all the screw and nylon lock nut connections.

### Step 3:



### Step 4:

