

**ULTRALIGHT. HEAVY-DUTY GUN SAFE** 

**Brand Name: ANSWER** Model: ANS-59-12

Ultralight, Heavy-Duty Gun Safe, 12-Gun Storage **Description:** 

Congratulations on the purchase of your new **ANSWER™ Ultralight, Heavy-Duty Gun Safe Product Specifications:** 

• W x D x H (External) 36" x 18" x 59"

• W x D x H (Internal) 35-7/8" x 14.5" x 58-3/4"

Weight 399 lb.

12 Gauge Steel

# **Door Specifications**

- Four 1" stationary bolts per hinge side
- Twelve 1" sliding bolts on open sides
  - Four on right-door handle side, four on top, four on bottom
- Six heavy-duty hinges
- Left door handle located internally

### **Included Components**

- CradleGrid<sup>™</sup> Technology
  - Upper Saddles w/ Bungees (12 ct.)
  - Stock Bases (6 ct.)
- SecuRam<sup>®</sup> SafeLogic<sup>™</sup> Entrypad
- Black Powder Coated Finish
- Power Hook-Up for Additional Accessories
- Internal Door Organizer
- · Storage Shelf

NOTE: MAKE SURE YOU STORE THIS DOCUMENT SOMEWHERE SECURE AND NOT INSIDE THE SAFE

# About Your ANSWER™ Ultralight, Heavy-Duty Gun Safe:

The Answer™ Ultralight Gun Safe Model 12 is an ultralight, heavy-duty gun safe system that provides storage for up to 12 rifles. Fully welded and weighing hundreds of pounds less than old-school gun vaults allows for flexible repositioning should you ever need to move it without compromising the security and safety you require to store your guns. Featuring CradleGrid™ Technology for organized and adaptable storage.

For More Information About SecureIt & Your Answer™ Ultralight, Heavy-Duty Gun Safe Visit Our Website: SecureItGunStorage.com

### Follow Us On:

Facebook - Facebook.com/GunStorage Twitter - @SecureItStorage Instagram - @SecureIt YouTube - YouTube.com/SecureItGunStorage







### ANSWER™ ULTRALIGHT, HEAVY-DUTY GUN SAFE MANUAL:

#### **CAUTION:**

• The ANSWER™ should be stored inside of a dry location.

# Installing CradleGrid™: Stock Bases & Upper Saddles

1) Take full advantage of Securelt's CradleGrid™ Technology by installing the included Upper Saddle with Bungees (12 count) and Stock Bases (6 count). Simply slide each Upper Saddle onto the louvered back panel at the desired height. Make sure that each saddle is flush with the back of the safe when adjusting.

Step - 1




2) Place each of the interlocking Stock Bases at the bottom of the cabinet with the *Securelt* logo facing front. Position the Stock Bases about 3 inches away from the back of the cabinet so your rifles and/or shotguns can rest at an optimal angle while stored.

Step - 2



3) Once your firearms are placed inside of the cabinet and the Upper Saddles are adjusted to the appropriate height of your firearms, you have the option to tighten the pan-head screw located underneath each saddle. This screw allows you to affix the saddle in a particular spot for as long as you desire.

Step - 3





# SecuRam® SafeLogic™ Entrypad – Set Up Guide

### **Important:**

- Always perform operations with the gun cabinet lock system unlock and the cabinet door open.
- Before closing the door, make sure all the program changes are correct.
- Duracell and Energizer Alkaline batteries recommended.

Your SafeLogic™ Entrypad comes with 2 pre-programmed entry codes:

- The Manager Code is set to 1-1-1-1-1
- The User Code is set to 1-2-3-4-5-6

#### Step 1: Open Lock

- Enter the User Code (Default Code is 1-2-3-4-5-6)
- The Lock Opens. It's that easy!

### **Step 2**: Changing your Code

- Enter "0" six times, you will hear 2 beeps
- Enter the existing code 1-2-3-4-5-6, you will hear 2 beeps
- Enter a new 6-digit code, you will hear 1 beep
- Re-enter the new 6-digit code, you will hear 1 beep

### That's it! Your Code has been successfully changed. You can now use your new code to open the lock.

### **About Manager Codes**

- The default Manager Code is 1-1-1-1-1.
- Follow "Step 2 (Above): Change your Code" to change the Manager Code but this time, enter the Manager Code of 1-1-1-1-1, instead of 1-2-3-4-5-6.
- The Manager Code will be changed and can be used as a second access code.
  Notice: Codes can be the same however, you will be limited to one code thereafter.

### **Entrypad Battery Replacement Guide**

Follow these steps to replace/install a 9V battery (not included) in your SecuRam® Safelogic™ Entrypad.

**Step 1**: Locate the battery compartment underneath the entrypad (See Fig. 1).

**Step 2**: Release the latch of the battery compartment by pulling the lever downward (See Fig. 2).

**Step 3**: Carefully guide the battery compartment out by its base to avoid damaging the latch (See Fig. 3).

**Step 4:** Take out the battery and replace with a new 9V alkaline battery (Duracell and Energizer brands are recommended). The battery compartment will receive the battery, orienting the positive and negative terminals correctly (See Fig.4.)

**Step 5**: Guide the battery compartment back into the entrypad. Push it up until it is in line with or level with the cover. Pull up the latch of the battery compartment until it is tight and secure too (See Fig. 1).

